

Cetol[®] Log Décor

Preparation Procedures for New, Unfinished Wood:

Remove hardware. This will make the preparation faster and easier. Hardware that cannot be removed should be taped. Clean the surface with a solution of four (4) ounces 100% powdered Tri-Sodium Phosphate (TSP) or phosphate-free substitute in one (1) gallon of warm water to remove grease, wax, dirt or oil. Do not allow cleaning solution to dry on the surface. Use a damp cloth or sponge to rinse and remove residue from the surface and allow to dry. Fill all holes and cracks with a high quality tinted or stained acrylic wood filler to match the color of the project. Let dry fully before sanding. Do not use oil based fillers, putties or wax sticks. Sand the surface using 150 - 180 grit sandpaper. Always sand wood with the grain to achieve a smoother surface without sanding marks. Remove sanding dust by vacuuming. Wipe the surface with a damp cloth to remove final dust particles.

Preparation Procedures for Finished Wood:

If the wood surface is damaged, the old coating contained wax, or if the old coating is incompatible with the new Sikkens finish, the surface should be stripped completely to bare, clean wood.

Standard Application Procedure:

Follow the preparation procedures. Apply one (1) coat of Cetol Log Décor. Let surface dry for minimum of four (4) hours. Lightly sand with 220 grit sandpaper or fine scuffing pad and remove the dust. Apply second coat of Cetol Log Décor. For high wear areas, apply a third coat of Cetol Log Décor after four (4) hours of dry. The second or third coat can be substituted with Cetol BL Interior Clear for less color or a different sheen.

General Recommendations:

Color Check - Always do a full system test on a piece of the same wood that will be used in the project.

When Mixing - Thoroughly stir the product before application. Never shake the product as this can cause bubbles to form in the coating. These bubbles may remain on the surface once the product has dried and create a rough finish.

Grain or Pore Filler - Some types of wood may require the use of an acrylic grain or pore filler that will help to achieve a smooth finish (in most cases it is applied on open-pored hardwoods such as oak, mahogany, teak and ash). Follow the manufacturer's instructions for application and drying time. Lightly sand the filler using 120 – 180 grit sandpaper until level with the surface. Remove any dust by vacuuming and wipe completely with a damp cloth.

Cetol[®] Log Décor

Maintenance Procedures and Schedule:

The longevity of the coating system depends on many factors such as daily wear and tear and exposure to ultraviolet light. Apply a refresher coat of Cetol Log Décor or Cetol BL Interior Clear when visually required.

Before application of a maintenance coat, prepare the surface using the previously mentioned TSP solution but reduce the amount to two (2) ounces of 100% powdered Tri-Sodium Phosphate or phosphate-free substitute. Use a damp cloth or sponge to rinse and remove residue from the surface and allow to dry. Fill all holes and cracks with a good quality tinted or stained acrylic wood filler to match the color of the project. Sand the project surface with 220 grit sandpaper. Remove sanding dust by vacuuming. Wipe the surface with a damp cloth to remove final dust particles. Apply one (1) or two (2) coats of depending on the extent of the wear.

Health and Safety Data:

Warning: Do not take internally. Keep out of reach of children. Close container after use.

First Aid Treatment:

Refer to the Material Safety Data Sheet found on the Sikkens website (www.nam.sikkens.com) or by calling Sales and Technical Support at 1-866-SIKKENS (1-866-745-5367).

Product Disclaimer:

The technical information and suggestions for use made herein are based on Akzo Nobel Paints LLC research and experience, and are believed to be reliable. Such information and suggestions do not constitute a warranty. Since Akzo Nobel Paints LLC has no control over the conditions under which the product is transported, stored, handled, used or applied, buyers must determine for themselves, by preliminary tests or otherwise, the suitability of the product for their purposes.